



## ZRP RZR XP/XPT RADIUS RODS

1. Place the frame of the RZR on jack stands so the tires are off the ground. Be sure it is solidly on the jack stands so it will not fall off. Remove both rear tires.
2. Remove all 4 radius rods – keep the bolts. You will re-use them. Note: You can do these 1 at a time - remove one and install a new one; then go to the next. Either way works.
3. Now install the new radius rods. Note that there are 2 different thicknesses of spacers for the upper radius rods. The thicker spacers go to the inside of the car, against the frame, and the thinner spacers so to the outside.
4. Tighten all bolts to spec (40ft-lb).
5. Repeat this process for all radius rods.
6. Double check that nuts on the heim joints are tight.
7. Mount tires, torque to spec.





Update:

- Thicker spacers go on the frame/chassis side and thinner spacers go toward the outside/Radius Rod Plate side.

