



Can Am Door Handle Kit

1. Remove plastic cover from door latch. Discard.
2. Drill out rivet holding on door strap. Discard.
3. Install ZRP door handle using provided bolts. Tighten.

